

PRO Power LED Accessory Battery System Instructions


The Lowel PRO Power LED Accessory Battery System is a professional product. Please read these, and PRO LED instructions fully before operating.



The PRO Power LED Battery System is a product of Lowel-Light, the Academy Award Winning World Leader in Location Lighting.




PRO Power LED Accessory Battery Box



- When attaching battery box to stand, place on lower stand sections for best balance.
- Plug battery cable into the same rear panel jack as the AC supply uses on PRO LED.
- Coil loose battery cable on reel and secure with rotating locking arms.
- When using handheld with shoulder strap, attach PRO Handle (G5-41) to screw-thread on bottom of light for best balance.

1. Hinged locking lid
2. Power cable reel and rotating locking arms
3. Stand locking clamp
4. Shoulder strap attachment rings

Charging the Battery



- Open box lid and remove battery.
- Plug Rapid Charger into battery as shown.
- Full charge takes approx. 1 hr.
- When fully charged, red LED indicator on charger will turn on green.

Orient battery correctly when reinserting



Lowel-Light Manufacturing, Inc.

90 Oser Avenue, Hauppauge, N.Y. 11788
Call: 800 645-2522 or 631-273-2500
Fax: 631-273-2557
e-mail: info@lowel.com
www.lowel.com

TIFFEN

lowel®